




HP ZBook 15 Hard Drive Disassembly

Prerequisite Only

Written By: Grant Terris



INTRODUCTION

Prerequisite Only



TOOLS:

- [Phillips #0 Screwdriver](#) (1)
-

Step 1 — Battery



- Flip the laptop over.
- Slide the lever with the battery symbol beside it firmly until the battery pops out.
- Remove the battery from the laptop.

Step 2 — Back Cover




- Slide the right lever firmly to the right.
- Slide the cover towards yourself to remove it.

Step 3 — HP ZBook 15 Hard Drive Disassembly



- Unscrew the three captive screws holding the drive in place with a Phillips #0 screwdriver.
- ⓘ The screws will remain inside the springs of the hard drive caddy cover.

Step 4



- Pull the green tab away from the metal casing and lift the drive out.

To reassemble your device, follow these instructions in reverse order.

This document was last generated on 2017-07-10 07:03:58 AM.

